

Fisher® 3570 Series Pneumatic Valve Positioners

Contents

Introduction	1
Scope of Manual	1
Description	2
Valve Positioner Type Numbers	2
Specifications	4
Educational Services	4
Installation, Mounting, and Connections	4
Installation	4
Diagnostic Test Connections (Optional)	5
Connections	6
Piping Sizes	6
Vent	6
Supply Pressure Connections	7
Cylinder Connections	8
Instrument Connection	8
Operating Information	8
Initial Adjustments	8
Signal Range Codes	8
Frequency Response	9
Adjustment Procedures	11
Changing Positioner Action	13
Split Range Operation	15
Initial Range Spring Extension Procedure for 3570P and 3570PC Positioners	15
Principle of Operation	16
3570, 3570C, 3570P, 3570PC, and 3571 Valve Positioners	16
3572 and 3576 Valve Positioners	17
3573 and 3577 Valve Positioners	17
Relay Operation	18
Maintenance	19
Troubleshooting	19
Converting a 3570 Valve Positioner to a 3570C Valve Positioner	20
Range Spring	21
Disassembly	21
Assembly	21
Bias Spring	21
Disassembly	21
Assembly	22
Parts Ordering	22
Parts Kits	22
Positioner Repair Kits	22
Diagnostic Test Connection Kits	22



W55667/L

Figure 1. Fisher® 3570 Positioner Mounted on 470 Actuator

Parts List	23
Positioner Common Parts	23

Introduction

Scope of Manual

This manual provides installation, operation, adjustment, maintenance, and parts ordering information for Fisher® 3570 Series pneumatic valve positioners. The various product types within this series are described later in this manual. Refer to figure 1 for a typical mounting of a 3570 positioner. Refer to separate instruction manuals for information concerning the actuator, valve, and accessories.



3570 Positioners

Do not install, operate or maintain a 3570 Series positioner without first ● being fully trained and qualified in valve, actuator and accessory installation, operation and maintenance, and ● carefully reading and understanding the contents of this manual. If you have any questions about these instructions, contact your Emerson Process Management sales office.

Description

The 3570 Series pneumatic valve positioners are used with control valve assemblies to provide an accurate valve stem position that is proportional to the input signal received from a control device. The input signal range can be 0.2 to 1.0 bar (3 to 15 psig), 0.4 to 2.0 bar (6 to 30 psig), or another pneumatic input signal range, as required.

These positioners are normally used with pneumatic piston actuators. However, product types within the 3570 Series can be used with pneumatic, long-stroke, cylinder actuators or with pneumatic diaphragm actuators.

Valve Positioner Type Numbers

3570 — Pneumatic valve positioner with two relays for use with Fisher 470 and 480 Series pneumatic piston actuators. See figure 2. The positioner includes three pressure gauges to monitor input signal, relay output pressure to the top of the actuator cylinder, and relay output pressure to the bottom (piston underside) of the actuator cylinder.

The 3570 positioner is mounted on the top of the actuator cylinder. The actuator stem position feedback is provided through extension of the range spring attached to the actuator piston rod.

3570C — Pneumatic valve positioner with automotive tire valves instead of pressure gauges. Tire valves can be used for clip-on test pressure gauges. The relay nozzles are locked in place with locknuts to resist unwanted nozzle movement due to vibration.

3570P — Pneumatic valve positioner with two relays for use with Fisher 490 Series pneumatic piston actuators. The positioner includes three pressure gauges to monitor input signal, relay output pressure to the top of the actuator cylinder, and relay output pressure to the bottom (piston underside) of the actuator cylinder.

The 3570P positioner is mounted alongside the actuator cylinder. Actuator stem position feedback is provided from the actuator-valve stem connector through a cable and spool assembly.

3570PC — Pneumatic valve positioner with automotive tire valves instead of pressure gauges. Tire valves can be used for clip-on test pressure gauges. The relay nozzles are locked in place with locknuts to resist unwanted nozzle movement due to vibration.

3571 (Discontinued)— Pneumatic valve positioner with two relays for use with long-stroke cylinder actuators. The positioner includes three pressure gauges to monitor input signal, relay output pressure to the top of the actuator cylinder, and relay output pressure to the bottom (piston underside) of the actuator cylinder.


The 3571 positioner is bracket-mounted to the side of the actuator. Actuator stem position feedback is provided through a wire from the actuator-valve stem connector.

3572 — Pneumatic valve positioner with one relay. The 3572 positioner is normally used on the 472 pneumatic piston actuator mounted on valve bodies having push-down-to-open (PDTO) action. The positioner includes two pressure gauges to monitor input signal pressure and relay output pressure to the top of the actuator cylinder.

The 3572 positioner is mounted on the top of the actuator cylinder. Actuator stem position feedback is provided through an extension of the actuator piston rod.

3573 — Pneumatic valve positioner that is similar to The 3572 positioner with the relay output pressure piped to the bottom (piston underside) of the actuator cylinder. The 3573 positioner is normally used on the 473 pneumatic piston actuator with valve bodies having push-down-to-close (PDTC) action.

Table 1. Specifications

<p>Available Configurations See the positioner type number descriptions given above.</p> <p>Input Signal Standard Ranges: 0.2 to 1.0 bar (3 to 15 psig) or 0.4 to 2.0 bar (6 to 30 psig) Optional Ranges: As desired, within the limits of the bellows Split Ranges: Use one-half of either standard range when two control valves are operated by one output signal from a single control device</p> <p>Output Signal Type: Pneumatic pressure as required to maintain the correct valve stem position and seat load Action: Field-reversible between direct and reverse</p> <p>Resolution⁽¹⁾ 0.2% of instrument pressure span</p> <p>Repeatability⁽¹⁾ 0.3% of total stroke or instrument pressure span</p> <p>Frequency Response⁽¹⁾ See figure 5</p> <p>Pressure Connections Vent: 3/8 NPT All others: 1/4 NPT</p> <p>Pressure Indications 3570C and 3570CP Positioners: Tire valves accept standard pressure gauge chucks (gauges not supplied) All Other Types: Gauges supplied per table 3</p> <p>Bellows Pressure Rating Standard Bellows: 3.4 bar (50 psig) Optional Bellows: 6.2 bar (90 psig)</p>	<p>Supply Pressure Maximum: 10.4 bar (150 psig) Minimum: 2.4 bar (35 psig)</p> <p>Supply Medium Air or Natural gas⁽²⁾</p> <p>Steady-State Air Consumption⁽³⁾ 0.54 normal m³/h (20 scfh) with 6.9 bar (100 psig) supply pressure</p> <p>Operative Ambient Temperature Limits⁽¹⁾ With Nitrile O-Rings and Diaphragms: -34 to 71°C (-30 to 160°F) With Fluorocarbon O-Rings and Diaphragms (Optional): 0 to 104°C (32 to 220°F)</p> <p>Hazardous Area Classification Complies with the requirements of ATEX Group II Category 2 Gas and Dust </p> <p>Options ■ Restrictor (high-frequency filter for bellows)</p> <p>Approximate Weight 2.7 kg (6 pounds) without optional mounting bracket or actuator/valve assembly</p> <p>Declaration of SEP Fisher Controls International LLC declares this product to be in compliance with Article 3 paragraph 3 of the Pressure Equipment Directive (PED) 97 / 23 / EC. It was designed and manufactured in accordance with Sound Engineering Practice (SEP) and cannot bear the CE marking related to PED compliance. However, the product <i>may</i> bear the CE marking to indicate compliance with <i>other</i> applicable European Community Directives.</p>
---	---

NOTE: Specialized instrument terms are defined in ANSI/ISA Standard 51.1 – Process Instrument Terminology.
1. For a 3570 or 3570C positioner mounted on a 470 or 480 actuator. Values do not apply to other constructions or actuator-valve combinations.
2. Natural gas should not contain more than 20 ppm of H₂S.
3. m³/h at 0°C, 1.01325 bar, absolute (Scfh at 60°F, 14.7 psia).

Table 2. Action Under Normal Operating Conditions

POSITIONER ACTION	DESIRED PISTON MOTION ⁽¹⁾	
	Down	Up
Direct-acting	Increasing input signal pressure to bellows	Decreasing input signal pressure to bellows
Reverse-acting	Decreasing input signal pressure to bellows	Increasing input signal pressure to bellows

1. Supply pressure is routed through relays to piston.

3570 Positioners

Table 3. Pressure Indications

PRESSURE MONITORED	NUMBER OF GAUGES SUPPLIED		STANDARD GAUGE RANGE ⁽¹⁾
	Two-Relay Positioner	One-Relay Positioner	
Positioner input signal pressure	1	1	0-30 psi/0-0.2 MPa/0-2 bar or 0-60 psi/0-0.4 MPa/0-4 bar
Cylinder (relay output) pressure	2	1	0-160 psi/0-1.1 MPa/0-11 bar

1. For gauges marked in other units and ranges, consult your Emerson Process Management sales office.

3576 (Discontinued)— Pneumatic valve positioner with one relay for use on direct-acting pneumatic diaphragm actuators that require high operating pressures. The 3576 positioner includes two pressure gauges to monitor input signal pressure and relay output pressure to the top of the actuator diaphragm.

The 3576 positioner is bracket-mounted to the actuator yoke. Actuator stem position feedback is provided through a wire from the actuator-valve stem connector.

3577 (Discontinued)— Pneumatic valve positioner that is similar to 3576 positioner with the relay output pressure piped to the underside of the actuator diaphragm on reverse-acting pneumatic diaphragm actuators.

Specifications

Specifications for the 3570 Series positioners are listed in table 1.

Educational Services

For information on available courses for 3570 Series positioners, as well as a variety of other products, contact:

Emerson Process Management
 Educational Services, Registration
 P.O. Box 190; 301 S. 1st Ave.
 Marshalltown, IA 50158-2823
 Phone: 800-338-8158 or
 Phone: 641-754-3771
 FAX: 641-754-3431
 e-mail: education@emersonprocess.com

Installation, Mounting, and Connections

Installation




- Always wear protective clothing, gloves, and eyewear when performing any installation operations to avoid personal injury.
- Personal injury or property damage may result from fire or explosion if natural gas is used as the supply medium and preventative measures are not taken. Preventative measures may include: Remote venting of the unit, re-evaluating the hazardous area classification, ensuring adequate ventilation, and the removal of any ignition sources. For information on remote venting of this positioner, refer to page 6.
- Check with your process or safety engineer for any additional measures that must be taken to protect against process media.
- If installing this into an existing application, also refer to the **WARNING** at the beginning of the Maintenance section of this instruction manual.

The positioner is usually mounted on the actuator at the factory. However, if the positioner and actuator are ordered separately, it is necessary to mount the positioner on the actuator. Before mounting the positioner, be certain the O-ring (key 33, figure 11) is in place in the cylinder (top connection) in the base of the positioner.

For appropriate actuator/positioner combinations, refer to the positioner type number descriptions given earlier in this instruction manual.

- For **3570, 3570C, 3572, and 3573 positioners**, mount the positioner with two cap screws (key 32, figure 11). If the range and bias springs are not installed in the positioner, refer to the range spring and bias spring procedures in the Maintenance section.



W40257/IL

W40277/IL

NOTES:

1 ON SOME CONSTRUCTIONS, TWO NOZZLES AND ADJUSTMENTS ARE REQUIRED.

Figure 2. Typical Location of Fisher® 3570 Positioner Parts and Adjustments

Insert the threaded end of the spring retainer (key 19, figure 3) into the center of the range spring (see figure 3). Then, insert a screwdriver into the center of the range spring and extend the spring until the spring retainer can be screwed into the top of the actuator piston rod extension. Tighten the spring retainer into the top of the actuator piston rod extension. If the range spring and/or bias spring is not installed in the positioner, refer to the procedures for either spring in the Maintenance section.

- **For 3570P and 3570PC positioners**, attach the positioner extension and positioner to the cylinder mounting plate with the two cap screws (key 100, figure 14). Make the required pressure connections as described in the following procedure. Go to the initial range spring extension procedures for 3570P and 3570PC positioners.

- **For 3571, 3576, and 3577 positioners**, insert two cap screws through the holes in the mounting bracket (key 55, figure 13) to attach the positioner to the actuator mounting boss. Attach the hex drive stud to the actuator-valve stem connection. Attach the end bearing (key 56E, figure 13) to the hex drive stud.

Diagnostic Test Connectors (Optional)

Diagnostic test connectors are available from the factory, when the unit is ordered, or they can be installed on an existing control valve assembly in the field. These connectors are especially useful for “quick” connections when using the FlowScanner™ valve diagnostic system. The FlowScanner is a portable, microprocessor-based diagnostic and calibration system specifically designed for use with pneumatically-operated control valves.

To support diagnostic testing of the control valve assembly, the connectors, piping, and other hardware can be installed between the 3570 Series positioner and the actuator. A typical connector installation is shown in figure 4. For connectors, refer to the FlowScanner Diagnostic Connection kit listing in the parts list.

The hardware used includes 3/4 NPT pipe nipple, pipe tee, and pipe bushings with a 1/8 NPT pipe bushing for the connector. The connector consists of 1/8 NPT body and body protector (see figure 4).

3570 Positioners




Figure 3. Bias and Range Springs for Zero and Span Adjustments

1. Before assembling the pipe nipple, pipe tee, pipe bushings, actuator piping, and connector body, apply sealant to all threads.
2. Position the pipe tee, connector body, and body protector for easy access when doing diagnostic testing.

Connections

Piping Sizes

All pressure connections on the 3570 Series positioners are 1/4 NPT (internal). Use 3/8-inch pipe or tubing for supply, cylinder (bottom connection), and instrument (input signal) connections. For the remote vent pipe, if one is required, use 19 mm (3/4-inch) (minimum inside diameter) pipe for runs up to 6.09 meters (20 feet). For vent piping runs from 6.09 to 30.5 meters (20 to 100 feet), use 25.4 mm (1-inch) (minimum inside diameter) pipe. Refer to figure 2 for the locations and sizes of connections.




Figure 4. Diagnostic Test Connections

Vent



Personal injury or property damage could result from fire or explosion of accumulated gas, or from contact with hazardous gas, if a flammable or hazardous gas is used as the supply pressure medium.

The positioner/actuator assembly does not form a gas-tight seal, and flammable or hazardous gas could leak from the assembly. Therefore, if the assembly is enclosed install a remote vent line from the enclosure. However, a remote vent pipe alone cannot be relied upon to remove all hazardous gas. Use adequate ventilation, and necessary safety measures. Vent line piping should comply with local and regional codes and should be as short as possible with adequate inside diameter and few bends to reduce case pressure buildup.

CAUTION

When installing a remote vent pipe, take care not to overtighten the pipe in

the vent connection. Excessive torque will damage the threads in the connection.

Note

The vent connection is always plugged with a pipe plug for 3570P and 3570PC positioners when mounted on 490 Series actuators.

The connection marked VENT (see figure 2) should be left open if the actuator is installed in the vertical position. However, the vent must be protected against the entrance of any foreign material that could plug it. Check the vent periodically to be certain it is not plugged.

If the actuator is mounted in other than the vertical position, be sure there is a vent and drain at the lowest point of the positioner. To do this, remove the pipe plug (key 36, figure 11) from the cover. Then, position the cover in such a way that the hole in the cover is at the lowest point. Plug the vent connection because the positioner is now vented through the cover.

Note

A remote vent is not possible with 3570P, 3570PC, 3571, 3576, and 3577 positioners.

If a remote vent is required, the vent line must be as short as possible with a minimum number of bends or elbows. Vent line piping should have a minimum inside diameter of 19 mm (3/4-inch) for runs up to 6.09 meters (20 feet) and a minimum inside diameter of 25.4 mm (1-inch) for runs from 6.09 to 30.5 meters (20 to 100 feet).

Supply Pressure Connections

 **WARNING**

Personal injury or property damage may occur from an uncontrolled process if the supply medium is not clean, dry, oil-free air, or noncorrosive gas. While use and regular maintenance of a filter that removes particles larger than 40 microns in diameter will suffice in most applications, check with an Emerson field office and industry instrument air

quality standards for use with corrosive air or if you are unsure about the proper amount or method of air filtration or filter maintenance.

 **WARNING**

To avoid personal injury or property damage resulting from the sudden release of pressure, do not install the valve assembly where service conditions could exceed the limits given in this manual or on the appropriate nameplates. Use pressure-relieving devices as required by government or accepted industry codes and good engineering practices.

 **WARNING**

If the supply pressure medium is corrosive, make sure the tubing and instrument components that contact the corrosive medium are of suitable corrosion-resistant material. The use of unsuitable materials might result in personal injury or property damage due to the uncontrolled release of the corrosive media.

The connection marked SUPPLY (see figure 2) must be provided with clean, dry air or a noncorrosive gas. Install a 40-micron filter and suitable equipment to dry the supply medium. Establish a maintenance cycle to ensure that the regulator and filter are working correctly.

CAUTION

The maximum allowable supply pressure to prevent damage to the components of the positioner, actuator, and valve is normally stamped on the actuator nameplate. Use a suitable supply pressure regulator to reduce the supply pressure source to the value stamped on the nameplate.

If this maximum supply pressure value is not available, use a supply pressure that does not exceed any of the following:

- The maximum supply pressure for the positioner as shown in table 1.

3570 Positioners

- The maximum pressure rating of the actuator, from the appropriate actuator instruction manual.
- The maximum allowable valve plug stem load for the specific valve body assembly being used. Contact your Emerson Process Management sales office for valve plug stem load information, if required.
- For diaphragm actuators, refer to the actuator instruction manual for the recommended supply pressure and use the larger value of the range listed.

The recommended supply pressure for use with piston actuators is the highest available supply pressure between 3.4 bar (50 psig) and the maximum limit determined by the actuator and positioner specifications. Selecting the highest pressure within the limits will minimize load error and will maximize stroking speed and thrust. For the lowest supply pressure that will assure satisfactory performance, the factors of valve plug unbalance force, valve plug seating force, and frictional force must be considered in the following relationship:

$$\text{Supply pressure, = } 98 \left[\frac{(\text{Valve unbalance, kg}) + (\text{Seating force, kg}) + (\text{Frictional force, kg})}{(\text{Area of the actuator piston, in square mm})} \right] + 0.7 \text{ bar}$$

OR

$$\text{Supply pressure, = } \left[\frac{(\text{Valve unbalance, pounds}) + (\text{Seating force, pounds}) + (\text{Frictional force, pounds})}{(\text{Area of the actuator piston, in square inches})} \right] + 10 \text{ psig}$$

Consult your Emerson Process Management sales office for the appropriate values for specific actuators, valves, and service conditions. The 0.7 bar (10 psig) is added to the equation to account for an approximate 0.7 bar (10 psi) differential pressure loss in the positioner. For spring-return piston actuators, the pressure required to compress the actuator spring completely must also be considered.

Cylinder Connections

1. The connection marked CYLINDER (see figure 2) is connected at the factory to the lower part of the cylinder (bottom) or to the lower diaphragm casing if the positioner is used with a pneumatic diaphragm actuator.

2. The cylinder top connection is a pressure passage located in the bottom of the positioner base (key 1, figure 11). On 3570 and 3570C positioners, an O-ring (key 33, figure 11) is used between the bottom of the positioner and the top of the actuator. On 3570P, 3570PC, 3571, 3576, and 3577 positioners, a mounting bracket (key 55, figure 13) is required. This mounting bracket connects to the bottom of the base. An O-ring (key 33, figure 11) is placed between the base and mounting bracket. This mounting bracket provides a 1/4 NPT connection for the positioner output. This connection is made at the factory if the positioner is ordered mounted to the actuator or if the mounting bracket is installed.

Instrument Connection

The connection marked INSTRUMENT (see figure 2) connects to the output signal connection of the control device. The positioner operates only on a pneumatic input signal; the input signal range is marked on the nameplate (key 23, figure 11). The maximum allowable input signal for positioners with standard or optional bellows is in table 1 (bellows pressure rating). The instrument connection is made at the factory when a complete control valve assembly with a valve-mounted control device is ordered. Otherwise, make field connections to the positioner from an appropriate control device. Refer to table 1 and the nameplate for input signal pressure ranges.

Operating Information

Initial Adjustments

Normally, no adjustments are necessary upon initial installation. The positioner is set at the factory for the travel, input signal range, and action specified in the order. Adjustment is necessary when operating conditions are changed, when the unit has been dismantled and reassembled, or when the control valve travel does not correspond to the desired input signal range. If the operating conditions have not changed but the positioner requires adjustment, refer to the adjustment procedures in this section. If the operating conditions have changed, first, refer to the signal range code descriptions, then, refer to the adjustment procedures.

Signal Range Codes

The range spring and the bias spring are matched to a specific input signal range and length of travel.

Also, the spring retainer length is matched to the application on the 3570, 3570C, 3572, and 3573 positioners. Refer to figure 3 for location of parts.

The signal range codes in table 4 are based on the following applications:

- **Codes for valve travels up to and including 50 mm (2 inches)** are used for actuators that have a 50 mm (2 inch) maximum travel. If the actuator maximum travel is greater than 50 mm (2 inches), an additional retainer spacer (key 235, see figure 3) is required. Refer to the parts list for the additional spring retainer spacer (key 235) part number.

- **Codes for valve travels greater than 50 mm (2 inches), up to and including 105 mm (4-1/8 inches)**, are used for actuators that have a 105 mm (4-1/8 inch) maximum travel, except the 480-12 or 480-15 Size 20 actuators which have a 54 mm (2-1/8 inch) maximum travel. If the actuator maximum travel is greater than 105 mm (4-1/8 inches), an additional retainer spacer are required. Refer to the parts list for the additional spring retainer spacer (key 235) part numbers.

- **Codes for valve travels greater than 105 mm (4-1/8 inches), up to and including 206 mm (8-1/8 inches)**, are for actuators that have a 206 mm (8-1/8 inch) maximum travel. If the valve travel is 105 mm (4-1/8 inches) or less, two additional spring retainer spacers are required. Refer to the parts list for the additional spring retainer spacer (key 235) part numbers.

If the input signal range and travel do not match any of the selections in table 4, consult your Emerson Process Management sales office for information. To change the springs, refer to the range and bias spring procedures in the Maintenance section.

From table 4, select the signal range that matches your application. Find the travel length for the application under the signal range selected, then use the code (from the direct or reverse column) that matches the direct or reverse operation of the positioner.

The first number in the code is used to identify the range spring, the letter in the code is used to identify the bias spring, and the second number (after the letter) is used to identify the spring retainer. For example, from table 4, for a signal range of 0 to 1.0 bar (0 to 15 psig), an actuator travel of 14.3 mm (9/16-inch), and direct action, the signal range code from table 4 is 6G3. The “6” indicates the range

spring. The “G” indicates the bias spring. The “3” indicates the spring retainer.

Note

It is necessary to add the bias spring seat (key 8) to a unit when changing from an extension type spring (key 9) to a compression type spring (key 48).

When planning to change the bias spring in an existing unit, inspect the unit first to determine if the current bias spring is an extension type spring (key 9) or a compression type spring (key 48). To change from an extension type spring to a compression type spring, it is necessary to add the bias spring seat (key 8). Refer to the appropriate procedures in the Maintenance section of this manual.

In some cases, it is necessary to add an additional spring retainer spacer or change from the standard bellows to the optional high pressure bellows. Table 4 footnotes indicate the use of an additional spring retainer spacer or high pressure bellows.

Use the code from table 4 while referring to tables 5, 6, and 7 to determine the part numbers for the range spring, bias spring, and spring retainer. Unless otherwise specified, use the standard bellows. Also, no spring retainer spacer is required unless the spacer is specified in the footnotes of table 4.

Frequency Response

Figure 5 shows how a 3570 or 3570C positioner with 470 or 480 actuator responds when the input signal pressure is cycled at a small amplitude (3 to 5 percent), and at an increasing frequency. Assume the cycling input signal and the movement of the actuator rod are represented by sine waves. As the actuator rod is forced to move faster, its motion begins to fall behind the input signal in both time (shown as phase lag) and amplitude (shown as normalized gain).

3570 Positioners


Table 4. Fisher® 3570 Signal Range Codes⁽¹⁾

SIGNAL RANGE 0 to 1.0 bar (0 to 15 psig)				SIGNAL RANGE 0.2 to 0.6 bar (3 to 9 psig)				SIGNAL RANGE 0.2 to 1.0 bar (3 to 15 psig)				SIGNAL RANGE 0.2 to 1.0 bar (3 to 15 psig)															
Travel		Code		Travel		Code		Travel		Code		Travel		Code													
mm	Inches	Direct	Reverse	mm	Inches	Direct	Reverse	mm	Inches	Direct	Reverse	mm	Inches	Direct	Reverse												
14.3	9/16	6G3	6D3	66.7	2-5/8	15G13	15A13	54	2-1/8 ⁽³⁾	4G1	4B1	190.5	7-1/2	19G5	19C5												
17.5	11/16	2G4	2G4	76.2	3	14G8	14A8	54	2-1/8 ⁽⁸⁾	4G8	4B8	193	7.6	19G8	19C8												
19	3/4	7A1	7C1	79.4	3-1/8	14G8	14A8	55.6	2-3/16	9G3	9B3	196.6	7-3/4	19G3	19B3												
20.6	13/16	7G1	7B1	82.6	3-1/4	14G8	14A8					57.1	2-1/4	9G3	9B3	198.9	7-13/16	19G8	19B8								
26.2	1-1/32	5A12	5D12	104.8	4-1/8	13G8	13A8					58.7	2-5/16 ⁽³⁾	9G2	9B2	203.2	8	19G8	19B8								
28.6	1-1/8	5C8	5C8	88.9	3-1/2	14G8	14A8					59.5	2-11/32	9G3	9B3	206.4	8-1/8	19G12	19B13								
																				30.2	1-3/16	12A13	12C13	96.8	3-13/16	14G8	14A8
38.1	1-1/2	8G5	8B5	101.6	4	14G8	14A8	63.5	2-1/2	9G3	9B3	SIGNAL RANGE 0.2 to 1.8 bar (3 to 27 psig)															
39.7	1-9/16	8G12	8B12	104.8	4-1/8	13G8	13A8					66.7	2-5/8	9B3	9B3	9.5	3/8	10A2	10D2								
44.5	1-3/4	8G5	8A5	117.5	4-5/8 ⁽²⁾	13G3	13A3					68.3	2-11/16	9G10	9B10	11.1	7/16	10A2	10D2								
50.8	2	8G5	8A5	127	5 ⁽³⁾	13G4	13A4					69.9	2-3/4	9G10	9B10	15.9	5/8	3A2	3D2								
																				79.4	3-1/8	9A3	9B3	73	2-7/8	9G5	9B5
101.6	4	9A12	9B12	165.1	6-1/2	13G3	13A3	74.6	2-15/16	9G5	9B5	22.2	7/8	11A5	11D5												
104.8	4-1/8	9G1	9B1	177.8	7	13G8	13A8									76.2	3	9G12	9A12	25.4	1	2C5	2C5				
127	5	21B8	21D8	203.2	8	18G8	18A8					78.5	3.09	9G8	9B8	28.6	1-1/8	2A5	2D5								
SIGNAL RANGE 0 to 2.0 bar (0 to 30 psig)				SIGNAL RANGE 0.2 to 1.0 bar (3 to 15 psig)								79.4	3-1/8	9G7	9B7	31.8	1-1/4	5G4	5D4								
15.9	5/8	10D2	10D2	3.2	1/8	17H4	17H4					82.6	3-1/4	9G10	9B10	33.3	1-5/16	2A12	2D12								
19	3/4	10D3	10D3	3.2	1/8 ⁽⁶⁾	10D3	10D3	84.9	3-11/32	9G8	9B8	38.1	1-1/2	2C10	2C10												
25.4	1	11A4	11D4	4	5/32	10D2	10H2					85.7	3-3/8	9G13	9B13	43.9	1.73	2G12	2D12								
28.6	1-1/8	11A5	11D5	6.4	1/4	10B4	10H4					86.5	3-13/32	9G10	9B10	47.6	1-7/8	2G10	2C10								
33.3	1-5/16	11A12	11D12	8.7	11/32	6A3	6C3					88.9	3-1/2	9G13	9B13	50.8	2	5G10	5D10								
38.1	1-1/2	11D12	11D12	9.5	3/8	6A3	6C3					92	3-5/8	9G13	9B13	54	2-1/8	12A3	12D3								
				50.8	2	2G5	2D5	11.1	7/16	6A4	6D4	92.9	3-21/32	9G8	9B8	54	2-1/8 ⁽⁸⁾	12G13	12D13								
54	2-1/8 ⁽²⁾	12G7	12D7	11.9	0.469	6A4	6D4	95.3	3-3/4	9G8	9B8					63.5	2-1/2	1A3	1D3								
54	2-1/8 ⁽⁸⁾	12G10	12D10	12.7	1/2	7G1	7C1	96.8	3-13/16	9G8	9C8					76.2	3	1B12	1D12								
76.2	3	12C3	12C3	14.8	0.582	5G4	5C4	100	3-15/16	21G8	21B8									79.4	3-1/8	1A12	1D12				
79.4	3-1/8 ⁽²⁾	12A8	12D8	15.9	5/8	7G3	7B3	101.6	4	21G8	21A8					82.6	3-1/4	4G1	4C1								
101.6	4	1G1	1D1	17.5	11/16	7G4	7B4	101.6	4 ⁽⁶⁾	14G1	14A1	101.6	4	4G1	4B1												
																104.8	4-1/8	1G1	1C1	11.9	0.469	6A4	6D4	104.8	4-1/8	16G8	16B8
11.1	7/16	5G5	5A5													19	3/4	7G4	7C4	108	4-1/4 ⁽⁴⁾	16G13	16D13	104.8	4-1/8	4G5	4D5
																12.7	1/2	8G5	8A5	20.6	13/16	7A5	7B5				
15.9	5/8	8G10	8A10													22.2	7/8	5G5	5C5	114.3	4-1/2 ⁽⁶⁾	20A8	20C8	127	5 ⁽⁶⁾	21A4	21D4
19	3/4	8G13	8A13	23.8	15/16	8G5	8B5	116.8	4.6 ⁽⁴⁾	16G4	16C4	133.4	5-1/4 ⁽⁶⁾	21A3	21D3												
22.2	7/8	8G8	8B8	25.4	1	8G5	8B5					117.5	4-5/8 ⁽²⁾	16G3	16B3	152.4	6 ⁽⁵⁾	16G3	16C3								
25.4	1	4G8	4B8									27	1-1/16	8G12	8B12	120.7	4-3/4 ⁽²⁾	16G3	16B3	190.5	7-1/2 ⁽²⁾	21G1	21D1				
												27	1-1/16	4G8	4B8	28.6	1-1/8	8G12	8B12	127	5 ⁽⁵⁾	14G1	14C1	203.2	8 ⁽⁴⁾	21G10	21D10
28.6	1-1/8	9G8	9A8									31.8	1-1/4	8G12	8B12	133.4	5-1/4 ⁽⁵⁾	16G10	16C10	SIGNAL RANGE 0.4 to 1.2 bar (6 to 18 psig)							
35	1-3/8	9G8	9A8					33.3	1-5/16	8G10	8C10	139.7	5-1/2 ⁽⁵⁾	14G1	14B1	19	3/4	5G5	5C5								
38.1	1-1/2	9G8	9A8	35	1-3/8	8G10	8B10	152.4	6 ⁽⁵⁾	13G3	13A3									28.6	1-1/8	8G12	8B12				
41.3	1-5/8	9G8	9A8					36.5	1-7/16	8G13	8B13									155.6	6-1/8 ⁽⁵⁾	13G3	13A3	38.1	1-1/2	8G8	8B8
								50.8	2	15G8	15A8									38.1	1-1/2	8G13	8B13	165.1	6-1/2 ⁽⁵⁾	13G3	13A3
54	2-1/8	15A1	15A1					39.7	1-9/16	8G8	8C8									169.9	6-11/16	20G3	20B3	54	2-1/8	9G3	9C3
54	2-1/8 ⁽⁸⁾	15G5	15A5					41.3	1-5/8	8G8	8B8	171.5	6-3/4 ⁽⁵⁾	13G5	13A5	54	2-1/8 ⁽⁸⁾	9G12	9B12								
58.7	2-5/16	15G1	15A1	44.5	1-3/4	8G8	8B8	173	6-13/16	20G3	20A3					76.2	3	9G5	9C5								
63.5	2-1/2	15G3	15A3					46	1-13/16	4G8	4C8									177.8	7	20G5	20C5	101.6	4	21G8	21B8
								47.6	1-7/8	4G7	4B7									181.8	7-5/32 ^(2,6)	13G1	13A1	104.8	4-1/8	16G8	16B8
								50.8	2	4G8	4B8									188.1	7-13/32	20G3	20B3	152.4	6 ⁽⁴⁾	13G1	13B1

-Continued-

Table 4. Fisher® 3570 Signal Range Codes⁽¹⁾ (Continued)

SIGNAL RANGE 0.4 to 1.2 bar (6 to 18 psig)				SIGNAL RANGE 0.4 to 2.0 bar (6 to 30 psig)				SIGNAL RANGE 0.6 to 1.0 bar (9 to 15 psig)				SIGNAL RANGE 0.6 to 1.0 bar (9 to 15 psig)			
Travel		Code		Travel		Code		Travel		Code		Travel		Code	
mm	Inches	Direct	Reverse	mm	Inches	Direct	Reverse	mm	Inches	Direct	Reverse	mm	Inches	Direct	Reverse
165.1	6-1/2 ⁽⁵⁾	13G3	13A3	57.1	2-1/4	12G1	12D1	8.7 11.1 12.7 15.9 17.5	11/32 7/16 1/2 5/8 11/16	5A13 5G5 12G13 8G8 8G8	5D13 5B5 12B13 8B8 8C8	104.8	4-1/8	14G8	14B8
206.4	8-1/8	19G5	19C5	58.4	2.3	12G3	12C3					117.5	4-5/8	13G3	13B8
SIGNAL RANGE 0.4 to 2.0 bar (6 to 30 psig)				60.3	2-3/8	12A10	12D10					127 152.4 155.6 165.1 177.8	5 ⁽³⁾ 6 6-1/8 6-1/2 7	13G12 13G3 13G4 13G12 13G3	13B12 13B3 13B4 13B12 13B3
				63.5	2-1/2	1G3	1H3								
				66.7	2-5/8	1G3	1D3								
6.4	1/4	17H4	17H4	69.9	2-3/4	1G4	1D4	19 25.4 28.6 38.1 41.3	3/4 1 1-1/8 1-1/2 1-5/8	8G10 4F8 9G8 9F8 9F8	8B10 4B8 9B8 9B8 9B8	203.2	8	18G8	18B8
9.5	3/8 ⁽⁶⁾	10A4	10H4	79.4	3-1/8	4G1	4C1					206.4	8-1/8	18G8	18B8
11.1	7/16	10A2	10H2	82.6	3-1/4	4G1	4C1					SIGNAL RANGE 1.2 to 2.0 bar (18 to 30 psig)			
12.7	1/2	10A2	10D2	84.1	3-5/16	4G3	4D3								
15.9	5/8	3G2	3H2	85.7	3-3/8	4G1	4H1					50.8	2	15G8	15B8
19	3/4	11G4	11H4	88.9	3-1/2	1G12	1D12	54	2-1/8	15G1	15B1				
22.2	7/8	11A5	11H5	90.5	3-9/16	4G1	4D1	54	2-1/8 ⁽⁸⁾	15F5	15B5				
25.4	1	2G4	2D4	92.9	3-21/32	4G14	4D1	58.7	2-5/16	15G1	15C1				
26.2	1-1/32	2G4	2H4	95.3	3-3/4	G1	4D1	63.5	2-1/2	15F1	15A1				
28.6	1-1/8	2G5	2D5	101.6	4	4G4	4D4	73	2-7/8	14G8	14B8	76.2	3	14G8	14B8
31.8	1-1/4	2G5	2D5	104.8	4-1/8	4G12	4D12	79.4	3-1/8	14G8	14B8	82.6	3-1/4	14G8	14B8
35	1-3/8	2G12	2D12	127	5 ⁽⁶⁾	21A5	21H5	82.6	3-1/4	14G8	14B8	87.3	3-7/16	14G8	14B8
38.1	1-1/2	5G5	5D5	133.4	5-1/4 ⁽⁶⁾	21A13	21D13	87.3	3-7/16	14G8	14B8	88.9	3-1/2	14G8	14B8
39.7	1-9/16	5G5	5D5	142.9	5-5/8 ⁽⁶⁾	16G1	16D1	90.5	3-9/16	20F8	20A8	133.4	5-1/4 ⁽³⁾	19F3	19D3
41.3	1-5/8	5G5	5D5	152.4	6 ⁽⁵⁾	16G3	16C3	96.8	3-13/16	14G8	14B8	165	6-1/2 ⁽⁵⁾	13F3	13B3
46	1-13/16	5G5	5D5	165.1	6-1/2 ⁽²⁾	16G1	16C1	101.6	4	14G8	14A8	206.4	8-1/8 ⁽⁵⁾	18F1	18D1
48.3	1.9	12G13	12H13	177.8	7 ⁽⁴⁾	21G12	21D12	1. For 3570P signal range codes, contact your Emerson Process Management sales office. 2. Use spring retainer spacer 1J803846172; for additional information, see table 7. 3. Use spring retainer spacer 1J223346172; for additional information, see table 7. 4. Use spring retainer spacer 1J803946172; for additional information, see table 7. 5. Use with high pressure bellows and spring retainer spacer 1J803946172; for additional information, see table 7. 6. Use with high pressure bellows. 7. Use with high pressure bellows and spring retainer spacer 1J223346172; for additional information, see table 7. 8. For use with 480-12 or 480-15 size 20 actuators.							
50.8	2	12C8	12C8	203.2	8 ⁽⁴⁾	21E12	21D12								
54	2-1/8 ⁽³⁾	12G7	12D7												
54	2-1/8 ⁽⁸⁾	12G13	12D13												



1. SIZE 30—19 mm (3/4 INCH) TRAVEL. 4. SIZE 80—51 mm (2 INCH) TRAVEL.
2. SIZE 40—38 mm (1-1/2 INCH) TRAVEL. 5. SIZE 100—51 mm (2 INCH) TRAVEL.
3. SIZE 60—38 mm (1-1/2 INCH) TRAVEL. 6. SIZE 130—76 mm (3 INCH) TRAVEL.
2K5255-R
A1285-2/IL

Figure 5. Typical Frequency Response for a Fisher® 3570 or 3570C Positioner Mounted on a 470 or 480 Actuator

Adjustment Procedures

Refer to figure 3. The 3570 Series positioners have three adjustments:

- **The bias spring.** It is the zero adjustment which determines the starting point of the valve plug travel.
- **The range spring.** It is the span adjustment which determines the full valve plug travel for a given input signal range.
- **The relay nozzle adjustment.** This adjustment determines the steady-state positioner output pressure.

To illustrate the use of the various adjustments, assume that the positioner has been repaired or has become completely out of adjustment. Assume also

3570 Positioners

that the input signal range is 0.2 to 1 bar (3 to 15 psig). Proceed as follows:

1. Make sure the input signal range and the valve travel stamped on the nameplate agree with the present operating conditions.
2. Loosen the four thumb screws on the underside of the positioner base and remove the cover.
3. Provide a means for varying the input signal pressure from zero to 0.07 or 0.14 bar (1 or 2 psig) above the higher value of the input signal range (see table 1). Provide an accurate means of measuring the input signal pressure. Check the accuracy of the positioner instrument pressure gauge (see figure 2). The gauge accuracy is ± 0.04 bar (± 0.6 psig) on a 0 to 2 bar (0 to 30 psig) gauge, and ± 0.08 bar (± 1.2 psig) on a 0 to 2 bar (0 to 60 psig) gauge. This accuracy is measured at the mid-point of the full range of the scale.
4. Set the input signal pressure at the mid-point of its range [0.6 bar (9 psig) in this example]. Observe the valve travel indicator scale attached to the yoke. The indicator disk should be somewhere between the open and closed positions.
5. Loosen the locknut directly below the bias spring seat (see figure 3) and adjust the bias spring up or down until the valve travel indicator disk shows that the valve plug is somewhere between the open and closed positions. Upward movement of the bias spring adjustment causes downward travel of the valve stem.
6. For positioners with two relays (3570, 3570C, 3570P, 3570PC, and 3571 positioners), observe the relay output pressures. If the cylinder gauges are present as shown in figure 2, read the cylinder top and cylinder bottom gauges or use clip-on test pressure gauges. The two relay output pressures should be approximately equal [within 0.3 bar (5 psig)] and should be approximately 75 percent of the supply pressure. For example, if the supply pressure is 7 bar (100 psig), the two relay output pressures should be within 0.3 bar (5 psig) of each other, and should be approximately 5.2 bar (75 psig).

CAUTION

The relays in the 3570C and 3570PC positioners use a locknut (key 29P, figure 11) on the nozzle (key 29Q). If the nozzle is rotated when the locknut is tight, damage to the relay diaphragm might result. Always use a wrench on the nozzle to prevent it from turning

while loosening or tightening the locknut.

If the relay output pressures are not at the values mentioned, adjust the nozzles. Counterclockwise rotation of either nozzle will move the nozzle closer to the beam and will increase relay output pressure.

For all 3570 Series positioners, examine the end of the beam near the bias spring (see figure 3). The beam should be approximately centered between the two E-ring travel stops. Observing the caution above for 3570C and 3570PC positioners, rotate the nozzle(s) to center the beam between the E-rings. For positioners with two relays, the relay output pressures must be approximately equal [within 0.3 bar (5 psig)] and approximately 75 percent of supply pressure after the beam is centered.

7. Apply an input signal equal to the low value of the input signal range [0.2 bar (3 psig) in this example]. Adjust the bias spring (see figure 3) up or down until the valve travel is at the starting point.
8. Loosen the spring lock (see figure 3) and slowly increase the input signal toward the high end of the input signal range [1.0 bar (15 psig) in this example]. If the valve travel is less than its expected range, increase the travel by adjusting the range spring counterclockwise. If the valve travel reaches the end of its expected range with an input signal less than the high value of the input signal range, decrease the travel by adjusting the range spring clockwise.
9. Repeat steps 7 and 8 until the valve plug or travel indicator action corresponds to the input signal requirements of the application [0.2 to 1.0 bar (3 to 15 psig) in this example].
10. Lock the range spring and the bias spring seat in position. The positioner is then ready for operation.
11. If the positioner is unstable and adjustment does not correct the problem, it might be due to unwanted fluctuations in the input signal. A restrictor assembly (key 47, figure 11) can be installed in the input signal circuit to dampen these fluctuations. The restrictor might help to minimize instability. To take the restrictor out of service, exchange the location of the restrictor with that of the bellows mounting screw (key 46, figure 11).

12. Replace the cover (key 39) on the positioner.

Table 5. Range^(1,2)

Code Number	Part Number ⁽³⁾
1	1H8914000A2
2	1H8915000A2
3	1H8916000A2
4	1H8917000A2
5	1H8918000A2
6	1H8919000A2
7	1H8920000A2
8	1H8921000A2
9	1H8922000A2
10	1H8955000A2
11	1H895627012
12	1H8957000A2
13	1J5185000A2
14	1J5715000A2
15	1K5363000A2
16	1K6684000A2
17	1R613527012
18	1R2822000A2
19	1R853527012
20	1R899827012
21	1U582727012
22	17A3811X022

1. The range spring code number is the first number given in each signal range code listed in table 4. For example, for a signal range of 0 to 1.0 bar (0 to 15 psig), an actuator travel of 14.3 mm (9/16-inch), and direct action, the signal range code from table 4 is 6G3. The appropriate range spring is indicated by "6".
 2. Range springs do not have a color code. All range springs are silver.
 3. The first six numbers of a range spring part number is also the tag number. For example, a range spring with part number 1H8914 000A2 has a tag number of 1H8914. Tags are attached to the parts at the time the parts are manufactured.

Table 6. Bias Spring^(1,2)

Code Letter	Color Code	Part Number
A	Silver	1H861827012 ⁽³⁾
B	Light blue	1H893227012 ⁽³⁾
C	Red	1H893327012 ⁽³⁾
D	Light green	1H896827012 ⁽³⁾
E	Dark green	1J2932X00A2 ⁽⁴⁾
F	Pink	1J2933000A2 ⁽⁴⁾
G	Black	1N7177000A2 ⁽⁴⁾
H	Brown	1R613427012 ⁽³⁾

1. The bias spring code letter is the letter given in each signal range code listed in table 4. For example, for a signal range of 0 to 1.0 bar (0 to 15 psig), an actuator travel of 14.3 mm (9/16-inch), and direct action, the signal range code from table 4 is 6G3. The appropriate bias spring is indicated by "C".
 2. It is necessary to add the bias spring seat (key 8) to a unit when changing from an extension type spring (key 9) to a compression type spring (key 48).
 3. Compression type bias spring (key 48).
 4. Extension type bias spring (key 9).

Table 7. Spring Retainer

CODE NUMBER ⁽¹⁾	OVERALL LENGTH ⁽²⁾		EFFECTIVE LENGTH ⁽²⁾		PART NUMBER ⁽³⁾
	mm	Inches	mm	Inches	
1	57	2-15/64	44	1-47/64	1H8907X0012
2	53	2-5/64	40	1-37/64	1H8908X0012
3	50	1-63/64	38	1-31/64	1H8909X0012
4	48	1-7/8	35	1-3/8	1H8911X0012
5	43	1-11/16	30	1-3/16	1H8910X0012
7	25	31/32	12	15/32	1H8912X0012
8	22	7/8	10	3/8	1H8552X0012
10	35	1-3/8	22	55/64	1H8913X0012
12	38	1-1/2	25	1	1J3572X0012
13	29	1-1/8	16	21/32	1J9796X0012

1. Code numbers 6, 9, and 11 are not used.
 2. Refer to figure 3.
 3. The spring retainer code number is the second number given in each signal range code listed in table 4. For example, for a signal range of 0 to 1.0 bar (0 to 15 psig), an actuator travel of 14.3 mm (9/16-inch), and direct action, the signal range code from table 4 is 6G3. The appropriate spring retainer is indicated by "3".

Table 8. Spring Retainer Spacer

OVERALL LENGTH ⁽¹⁾		EFFECTIVE LENGTH ⁽¹⁾		PART NUMBER ⁽²⁾
mm	Inches	mm	Inches	
41	1-5/8	29	1-1/8	1L2069X0012
52	2-1/16	40	1-9/16	1J223346172
57	2-1/4	44	1-3/4	1J803846172
94	3-11/16	81	3-3/16	1P3957X0012
97	3-13/16	84	3-5/16	1J803946172

1. Refer to figure 3.
 2. The spacer number is the first 6 characters of the part number and is stamped on the part.

Changing Positioner Action

The instructions given below are to be used after the springs have been changed or if no spring change is required. Numbered parts mentioned in this section are shown in figure 6 unless otherwise noted.

3570 Positioners




Figure 6. Bellows Mounting for Direct and Reverse Action

WARNING

The following procedures require taking the positioner, actuator, and control valve assembly out of service. To avoid personal injury or property damage caused by uncontrolled process pressure, provide a temporary means of control for the process before taking the assembly out of service.

Before removing the input signal and supply pressure connections from the positioner, remove the input signal and supply pressure sources from the connections. The sudden release of pressure can cause personal injury or property damage.

Note

Changing the positioner action might require changing the bias spring and/or the spring retainer. Refer to table 4 for correct signal range codes. Refer to the Maintenance section for disassembly and assembly procedures.

Changing to Reverse Action

1. Bypass the control valve and shut off the input signal line and the supply pressure line to the positioner.
2. Loosen the four thumb screws on the underside of the positioner base and remove the cover.
3. Two bellows posts are provided. The posts are screwed into storage holes in the positioner base immediately above the CYLINDER and INSTRUMENT connections. Unscrew these posts.

Note

An optional restrictor (see the top view in figure 6) can be found in place of one of the bellows mounting screws (number 1). If so, note the location of the restrictor and replace it in the same location during reassembly. The restrictor has a hex head; the mounting screws do not.

4. Remove the four mounting screws (numbers 1 and 2) and lift out the bellows assembly.
5. Screw the bellows posts (number 3) into the holes where the screws (number 1) originally were.
6. Invert the bellows and replace the screws (numbers 1 and 2).
7. Refer to the adjustment procedures to check operation of the positioner.
8. Make a notation on the action label (key 43, figure 11) that the action of the positioner has been changed.
9. Replace the cover (key 39) on the positioner.

Changing to Direct Action

1. Bypass the control valve and shut off the input signal line and the supply pressure line to the positioner.
2. Remove the positioner cover by loosening the four thumb screws on the underside of the base.

Note

An optional restrictor (see the top view in figure 6) can be found in place of one of the bellows mounting screws (number 1). If so, note the location of the restrictor and replace it in the same location during reassembly. The restrictor has a hex head; the mounting screws do not.

3. Remove the four mounting screws (numbers 1 and 2), bellows, and bellows posts (number 3).
4. Invert the bellows and reinstall it in the positioner. Secure the bellows with the four screws (numbers 1 and 2). Screw the bellows posts into the storage holes provided in the base immediately above the cylinder and instrument connections.
5. Refer to the adjustment procedures to check the operation of the positioner. If the input signal range has not been changed, adjustment of the range spring might not be necessary.
6. Make a notation on the positioner action label (key 43, figure 11) that the action of the positioner has been changed.
7. Replace the cover (key 39) on the positioner.

Split Range Operation

The 3570 Series valve positioners are suitable for split range operation. In split range operation, two or more control valves are operated by one output signal from a single control device. When two control valves are split ranged, one valve strokes fully with one half the input signal range and the second valve strokes fully with the other half of the input signal range.

Valve positioners shipped from the factory for split range operation are constructed and adjusted accordingly. If it is necessary to convert an existing positioner to one suitable for split range operation, refer to table 4. If the application requires a selection not listed in table 4, consult your Emerson Process Management sales office to determine the new parts required. For most changes, a new range spring and possibly a new bias spring will be required. A new range spring retainer might also be required for 3570, 3570C, 3572, and 3573 positioners.

When corresponding with your Emerson sales office, supply all information possible about the desired operating conditions and the serial numbers of the control valve assembly. This information will facilitate the proper selection of the required parts.

To change an existing valve positioner to one suitable for split range operation, refer to the range and bias spring removal and replacement procedures in the Maintenance section. Be certain the required new parts are on hand before beginning any maintenance operation.

Initial Range Spring Extension Procedures for 3570P And 3570PC Positioners

This procedure must be performed whenever the range spring has been changed or the positioner has been removed. Key numbers used in this procedure are shown in figure 14 except where indicated.

1. With the cap screw (key 87) removed, hook the small ball of the positioner cable (key 91) into the slot of the smaller portion of the cable spool (key 96). Wind the cable on the spool until the coils of the range spring (key 18, figure 11) are slightly separated. Be certain the cable is wound so that it comes off the side of the spool opposite the access opening and that the cable cannot cross itself on the spool.
2. Install the ball end of the actuator cable (key 92) into the slot of the large portion of the spool that is closer to the access opening. Wrap the cable on the spool as many times as possible, then bring the cable out through the bottom of the positioner extension. Be certain the cable is wound so that it comes off the side of the spool opposite the access opening and that the cable cannot cross itself on the spool. Attach the cable to the cable strap (key 93), leaving approximately a 0.8 mm (1/32-inch) gap between the cable eye and cap screw head (key 94).
3. With the actuator piston rod completely retracted and the range spring coils slightly separated, attach the cable strap to the actuator feedback arm. Use the set of cable-strap holes closest to the range spring. Turn the spring cap (key 86) one turn counterclockwise and install one cap screw (key 87).
4. Adjust the range spring (key 18, figure 11) to obtain full travel for the input signal range (span adjustment). Refer to step 7 of the adjustment procedures. Adjustment of the bias spring (zero adjustment) does not need to be done at this time.
5. Remove the screw from the spring cap and slowly release the torsion spring force by turning the spring cap clockwise. Disconnect the cable strap from the actuator and remove all range spring extension by rotating the cable spool.
6. Rotate the cable spool to obtain the correct initial range spring extension. Each full revolution of the spool extends the range spring 50.8 mm (2 inches) [6.4 mm (1/4-inch) for 1/8 revolution]. If the initial range spring extension is not specified, calculate it using one of the equations given below. Round off the amount of extension (e) obtained from the equation to the next higher 6.4 mm (1/4 inch).

3570 Positioners

$$e = \frac{T}{1.87 (P_n)} \text{ (standard bellows)}$$

$$e = \frac{T}{1.25 (P_n)} \text{ (optional high pressure bellows)}$$

where:

e = initial range spring extension required in mm

T = actuator travel in mm

P_n = input signal span in bar (for example, 0.8 bar for

a 0.2 to 1 bar input signal range)

or where:

e = initial range spring extension required in inches

T = actuator travel in inches

P_n = input signal span in psi (for example, 12 psi for

a 3 to 15 psig input signal range)

7. If necessary, move the actuator cable ball to the spool slot nearer the access opening. With the actuator piston rod fully retracted and the range spring at the correct initial extension, attach the cable strap to the actuator feedback arm. Use the set of cable strap holes that is closest to the tapped holes in the feedback arm.

8. Refer to the positioner adjustment procedures.

Principle of Operation

3570, 3570C, 3570P, 3570PC, and 3571 Valve Positioners

Refer to the schematic diagram in figure 7. The pneumatic output signal from a control device is piped to the positioner bellows. For explanation purposes, assume this signal has increased. The bellows expands and moves the beam, which pivots around a fixed point and simultaneously uncovers the nozzle of relay B and covers the nozzle of relay A. The nozzle pressure in relay A increases due to





Figure 7. Schematic Diagram of Fisher® 3570 Positioner with a 470 Series Pneumatic Piston Actuator

the restriction created by the beam covering the nozzle. Through relay action, the pressure to the top of the piston increases. At the same time, relay B reacts to the change in beam position to decrease the pressure to the underside of the piston. These unbalanced pressures move the actuator piston down.

In the 3570 and 3570C positioners, the piston movement is fed back to the beam by means of a range spring, which is connected to the beam and to the piston rod extension. In the 3570P, 3570PC, and 3571 positioners, the feedback is provided to the range spring by a cable or wire that is connected to the actuator-valve stem connector. The downward movement of the piston rod extension extends the range spring until the torque on the beam balances the torque exerted by the instrument bellows.

As the input signal decreases, the reverse action takes place. The bellows contracts, and as the beam pivots, it covers the nozzle of relay B and uncovers the nozzle of relay A. Through relay action, the pressure below the piston increases and the pressure above the piston decreases to move the piston upward.



CR4006-A
A1084-1/L

Figure 8. Schematic Diagram of Fisher® 3572 Positioner with a 472 Pneumatic Piston Actuator

3572 and 3576 Valve Positioners

Refer to the schematic diagram in figure 8, which shows the 3572 positioner mounted on a 472 pneumatic piston actuator. For the 3576 positioner, the principle of operation is identical to the 3572 positioner but the actuator can be a direct or reverse acting pneumatic diaphragm actuator.

The pneumatic output signal from a control device is piped to the positioner bellows. For explanation purposes, assume this signal has increased. The bellows expands and moves the beam, which pivots around a fixed point and covers the relay nozzle. The nozzle pressure in the relay increases due to

the restriction created by the beam covering the nozzle. Through relay action, the pressure above the piston overcomes the force exerted by the actuator spring, and the piston moves downward. This changes the valve plug position.

In the 3572 positioner, piston movement is fed back to the beam by means of a range spring, which is connected to the beam and the piston rod extension. As the piston rod extension moves downward, the range spring is extended until the torque of the beam balances the torque exerted by the instrument bellows.

In the 3576 positioner, the feedback is provided to the range spring by a wire that is connected to the actuator-valve stem connector.

As the input signal decreases, the reverse action takes place. The bellows contracts, and as the beam pivots, it uncovers the relay nozzle. Through relay action, the pressure on top of the piston decreases, and the force of the actuator spring moves the piston upward.


3573 and 3577 Valve Positioners

Refer to the schematic diagram in figure 9, which shows the 3573 positioner mounted on a 473 pneumatic piston actuator. For the 3577 positioner, the principle of operation is identical to the 3573 positioner, but the actuator can be direct or reverse acting.

The pneumatic output signal from a control device is piped to the positioner bellows. For explanation purposes, assume this signal has increased. The bellows expands and moves the beam, which pivots around a fixed point and uncovers the relay nozzle. The nozzle pressure decreases due to the uncovering of the nozzle by the beam. Through relay action, the pressure to the underside of the piston decreases. The force exerted by the actuator spring overcomes the force of the pressure below the piston, and the piston moves downward. This changes the valve plug position.

In the 3573 positioner, piston movement is fed back to the beam by means of a range spring, which is connected to the piston rod extension. The downward movement of the piston rod extension extends the range spring until the torque of the beam balances the torque exerted by the instrument bellows.

3570 Positioners



CR4007-A
A1082-1/IL

Figure 9. Schematic Diagram of Fisher® 3573 Positioner with 473 Pneumatic Piston Actuator

In the 3577 positioner, feedback is provided to the range spring by a wire that is connected to the actuator-valve stem connector.

As the input signal decreases, the reverse action takes place. The bellows contracts, and as the beam pivots, it covers the relay nozzle. Through relay action, the pressure on the underside of the piston increases to overcome the force exerted by the actuator spring, and the piston moves upward.

Relay Operation

Refer to figure 10, which shows a sectional view of a typical relay.




Figure 10. Sectional View of a Typical Relay

Supply pressure reaches the relay(s) through passages in the positioner base and is channeled to fixed restriction R and to point A between the supply valve B and the balancing O-ring of the relay valve. The fixed restriction is an integral part of the relay restriction plug and wire assembly G. The orifice in nozzle F is larger than the fixed restriction. This allows the supply pressure to bleed to atmosphere faster than it enters the unit through the fixed restriction when the beam flapper is away from the nozzle.

Assume that a change in the input signal causes the beam flapper to cover the nozzle of a relay. The supply pressure flows through fixed restriction R into the chamber between the two relay diaphragms. Due to the restricting effect of the flapper over the nozzle, pressure builds up in the chamber between the diaphragms, forcing the diaphragm head

assembly E downward to open supply valve B, allowing output pressure to increase.

The supply pressure flows past supply valve B to increase the output pressure to the actuator cylinder. The cylinder pressure (relay output pressure) also acts on the area D. This provides an air feedback that returns the diaphragm head assembly E and the movable nozzle F to their original positions, thus preventing any further increase in output pressure. The feedback arrangement and the movable nozzle ensure accurate and stable positioning of the actuator piston without introducing cycling or over-correction. After any change in the output pressure, supply valve B and exhaust valve C always return to the closed position to put the nozzle back in its original, or equilibrium, position. The spring behind supply valve B aids in closing the valve as the diaphragm head assembly is forced upward.

When the beam flapper moves away from the nozzle F, the supply pressure bleeds out at a greater rate than it enters through the fixed restriction R. The pressure then decreases in the chamber between diaphragms. The force of the cylinder pressure acting on area D pushes diaphragm head assembly E upward, opening exhaust valve C. Cylinder pressure bleeds through the exhaust port to atmosphere. As the cylinder pressure decreases and the force on area D decreases, the force of the nozzle pressure in the chamber between the diaphragms returns the assembly to its original position. The unit is again in equilibrium, but at a lower nozzle pressure and a lower output pressure.

Each relay has a 4:1 ratio between the nozzle pressure and the output pressure. For example, a 0.7 bar (10 psig) nozzle pressure change, produces a 2.7 bar (40 psig) output pressure change; a 1.4 bar (20 psig) nozzle pressure change produces an 5.5 bar (80 psig) output pressure change. With a constant input signal pressure, the internal parts of the relay are at equilibrium with the supply and exhaust valves closed.

Maintenance

Parts are subject to normal wear and must be inspected periodically and replaced as necessary. The frequency of parts inspection and replacement depends upon the severity of service conditions. When inspection or repairs are required, disassemble only those parts necessary to accomplish the task.

WARNING

Avoid personal injury from sudden release of process pressure. Before performing any maintenance operations:

- **Always wear protective clothing, gloves, and eyewear.**
- **Disconnect any operating lines providing air pressure, electric power, or a control signal to the actuator. Be sure the actuator cannot suddenly open or close the valve.**
- **Vent the power actuator loading pressure and relieve any actuator spring precompression.**
- **Use lock-out procedures to be sure that the above measures stay in effect while you work on the equipment.**
- **Personal injury or property damage may result from fire or explosion if natural gas is used as the supply medium and preventative measures are not taken. Preventative measures may include: Remote venting of the unit, re-evaluating the hazardous area classification, ensuring adequate ventilation, and the removal of any ignition sources. For information on remote venting of this positioner, refer to page 6.**
- **Check with your process or safety engineer for any additional measures that must be taken to protect against process media.**

Troubleshooting

If the positioner causes sluggish or erratic operation or the malfunctioning of the actuator, first, be certain that the range springs, bias springs, and spring retainer are correct for the application. Refer to table 4 or consult your Emerson Process Management sales office.

If the springs and spring retainer are correct, and careful adjustment of the unit does not produce smooth and satisfactory operation, check the following points. Key numbers used in this procedure are shown in figure 11 except where indicated. Figure 2 shows part locations.

3570 Positioners

1. Clean out the primary orifice on each relay by depressing the clean-out plunger. The plunger is located in the orifice assembly (key 29S). This operation runs a fine wire through the orifice to clear the hole.
2. Check the nozzle (key 29Q) of each relay for plugging. To clean, swing the flapper (key 12) away from the nozzle by loosening the screw that holds the flapper in place.

CAUTION

The relays used in 3570C and 3570PC positioners use a locknut (key 29P, figure 12) on the nozzle (key 29Q, figure 12). If the nozzle is rotated when the locknut is tight, damage to the relay diaphragm will result. Always use a wrench on the nozzle to prevent it from turning while loosening or tightening the locknut.

Unscrew the nozzle and run a fine wire through it. Do not enlarge the hole. Also check the surface of the flapper for any accumulation of dirt or foreign materials.

3. Check the bellows assembly for damage, misalignment, or leakage. Also check all gasketed joints for leakage. Use soap solution for leak detection.
4. Check the beam for damage, binding or rubbing against stationary parts. Check the flexure strip screws (key 17) for tightness.
5. If the positioner operation has improved, refer to the adjustment procedures.
6. If the relays require replacement, go to step 7.
7. Unscrew the three machine screws (key 31) from each relay and remove the relays.
8. Mount the relays in their respective positions on the positioner pedestal, making certain that the relay gasket (key 30) is in good condition and is in place.
9. If the positioner operation is still sluggish, a slight adjustment of the bias spring post (see figure 3) might be necessary. Loosen the locknut and rotate the post in half-turn increments, checking after each half turn for proper operation. Rotate the post no more than two turns from the position shown in figure 3. Refer to the adjustment procedures after rotating the post to check the position of the post and beam assemblies.

Converting a 3570 Valve Positioner to a 3570C Valve Positioner

If desired, tire valves can be substituted for pressure gauges. Also, locking relay nozzles can be added on any 3570 Series positioner. This provides the construction that is standard with 3570C and 3570PC positioners.

Key numbers used in this procedure are shown in figure 11 except where indicated. When reassembling, coat all pipe threads with a good quality pipe thread compound.

1. Isolate the control valve from the line pressure and release pressure from both sides of the valve body. If using a power actuator also shut-off all pressure lines to the power actuator and release all pressure from the actuator. Use lock-out procedures to be sure that the above measures stay in effect while you work on the equipment.
2. Loosen the knurled screws (key 38) and remove the cover (key 39).
3. Disconnect the tubing assemblies (keys 28 and 45) from the base and from the gauges (keys 24 and 25). Unscrew the hex nuts (key 27) from the back of the gauges and remove the gauges (keys 24 and 25).
4. Unscrew the pressure gauge (key 54) from the gauge adaptor (key 29U).
5. Unscrew and remove the nozzle and spring (keys 29Q and 29P) from each relay.
6. The gauge bracket (key 5) can be removed if desired. To remove it, loosen the locknut (key 7) and remove the bias spring post and cap screw (keys 6 and 32). When replacing the bias spring post, be sure that the bottom of the post thread is positioned as shown in figure 3 for proper positioning of the E-ring travel stops. This alignment can be verified visually through the vent port.
7. Use compression plugs (key 52) to plug the holes opened in the base when the tubing is removed.

CAUTION

Never rotate the nozzle (key 29Q) when the locknut (key 29P) is tight, or damage to the relay diaphragm will result. Always use a wrench on the nozzle to prevent it from turning while loosening or tightening the locknut.

8. Install the locknut and nozzle (keys 29P and 29Q) on each relay.

9. Install the tire valve (key 26, figure 12) into the gauge adaptor (key 29U).
10. Install the service tee and tire valve adaptor (keys 49 and 53, figure 12) into the CYLINDER connection. Connect the pressure line that runs to the lower part of the cylinder to the service tee.
11. Install the pipe nipple, pipe tee, and tire valve adaptor (keys 50, 51, and 53, figure 12) into the INSTRUMENT connection. Connect the input signal line to the pipe tee.
12. Refer to the adjustment procedures.

Range Spring

Disassembly

Unless otherwise directed, key numbers refer to figures 11 and 12.



WARNING

The following procedure requires taking the positioner, actuator, and control valve assembly out of service. To avoid personal injury or property damage caused by uncontrolled process pressure, provide a temporary means of control for the process before taking the assembly out of service.

Before removing the input signal and supply pressure connections from the positioner, remove the input signal and supply pressure sources from the connections. The sudden release of pressure can cause personal injury or property damage.

1. Bypass the control valve and shut off the input signal and the supply pressure lines to the positioner.
2. Remove the positioner cover (key 39).
3. Loosen the spring lock (see figure 3) that holds the range spring (key 18) to the beam.
4. Disconnect the other end of the range spring by performing one of the following steps:
 - **For 3570, 3570C, 3572, and 3573 positioners**, use a screwdriver to remove the spring retainer (key 19, figure 3) from the piston rod extension.

- **For 3570P and 3570PC positioners** (see figure 12), remove the screws (key 87), from the cap (key 86) and rotate the cap clockwise to remove all torsion spring force. Disconnect the actuator cable (key 92) from the cable strap (key 93). Unhook the positioner cable (key 91) from the cable spool (key 96).

- **For 3571, 3576, and 3577 positioners**, loosen the set screw found in the spring retainer (key 56A, figure 13) and remove the spring wire (key 56D) from the retainer.

5. Remove the range spring from the beam by rotating the range spring counter clockwise.

Assembly

1. Install the new range spring. For 3570, 3570C, 3572, and 3573 positioners, also install the spring retainer. See figures 3 or 11.
2. Reconnect the range spring to the piston rod extension (3570, 3570C, 3572, and 3573 positioners) or the feedback wire (3571, 3576, and 3577 positioners, figure 13). For 3570P and 3570PC positioners, install the positioner cable (key 91, figure 14) in the range spring so that the large ball on the cable seats in the conical portion of the spring.
3. Install the spring lock (key 20, figure 11). Adjust the positioner per instructions in the adjustments procedures.

The action of the positioner can be reversed in the same manner as described in the changing positioner action procedures. However, before attempting to reverse the action, see table 4 or consult your Emerson Process Management sales office to determine if any different parts are required.

Bias Spring

Disassembly

1. Refer to figure 3. Remove the top E-ring travel stop.
2. Loosen the locknut securing the bias spring seat in place. Then rotate the adjusting screw until the spring force is at a minimum.
3. Loosen the locknut that secures the bias spring post to the positioner base. Using a screwdriver in the slot in the top of the post, unscrew the post from the base.
4. Tilt the bottom of the post out and remove the post from the beam.

3570 Positioners

5. Remove the locking nuts and the spring seat from the bias spring post.

Assembly

1. Install the new bias spring, spring seat, and locking nuts on the bias spring post.
2. Replace the bias spring post into the beam and install the top E-ring travel stop.
3. Install the bias spring post into the base. Be certain that the bottom of the post thread is positioned as shown in figure 3. Ensure that the beam does not rub on the post.
4. For 3570P and 3570PC positioners, go to the initial range spring extension procedures for 3570P and 3570PC positioners.
5. Adjust the positioner as described in the adjustments procedures.

The action of the positioner can be reversed in the same manner as described in the changing positioner action procedures. However, before attempting to reverse the action, see table 4 or consult your Emerson Process Management sales office to determine if a different retainer, different range springs or different bias springs are required.

Parts Ordering

A serial number is assigned to each positioner. The serial number is stamped on the nameplate. Always refer to the serial number when corresponding with your Emerson Process Management sales office regarding spare parts or technical information. When ordering replacement parts, also specify the complete 11-character part number from the parts kits or parts list information.



WARNING

Use only genuine Fisher replacement parts. Components that are not supplied by Emerson Process Management should not, under any circumstances, be used in any Fisher instrument. Use of components not supplied by Emerson may void your warranty, might adversely affect the

performance of the valve, and could cause personal injury and property damage.

Note

Neither Emerson, Emerson Process Management, nor any of their affiliated entities assumes responsibility for the selection, use, or maintenance of any product. Responsibility for proper selection, use, and maintenance of any product remains with the purchaser and end-user.

Parts Kits

Note

Parts kits for the 3570 Series positioners contain the gaskets, diaphragms, and O-ring seals as specified by the type and temperature limitations. Parts are for 3570, 3570C, 3570P, and 3570PC positioners.

Positioner Repair Kits

Description	Part Number
Positioner kit includes: Keys 3, 12, 29 (qty. 2), 30, 33, and 37	
For the 3570	R3570X00022
For the 3570C	R3570CX0022
For the 3570C (hi-temp. const.)	R3570CX0H32

Diagnostic Test Connection Kits

Note

Part numbers are shown for recommended spares only. For part numbers not shown, contact your Emerson Process Management sales office.

Kit includes pipe tee, pipe nipple, pipe bushings, connector body, and body protector used with the FlowScanner.


For Diaphragm Actuators

- Stainless steel
- Steel

For Piston Actuators

- Stainless steel
- Steel

Pipe Thread Sealant (not furnished with hardware or connectors)



NOTES:

- 1 ZERO ADJUSTMENTS IS PART OF KEY 9 FOR EXTENSION TYPE BIAS SPRING.
- 2 ZERO ADJUSTMENTS IS PART OF KEY 9 FOR EXTENSION TYPE BIAS SPRING.

40A8973-C
B1840/IL

Figure 11. Fisher® 3570 Positioner

Parts List

Positioner Common Parts
(figures 11 and 12)


Note

Part numbers are shown for recommended spares only. For part numbers not shown, contact your Emerson Process Management sales office.

Key	Description	Part Number
1	Pilot base, aluminum	
2	Pedestal, aluminum	
3*	Pedestal gasket Chloroprene (std. const.) Fluorocarbon (hi-temp. const.)	1H854703012 1H8547X0012
4	Machine screw, pl steel (5 req'd)	
5	Gauge bracket, pl steel For all types except 3570C	
6	Bias spring post, pl steel	
7	Hex nut, pl steel (2 req'd)	
8	Spring seat, pl steel (use with key 48 only)	

*Recommended spare parts

3570 Positioners



40A8972-B
B1841/IL

Figure 12. Fisher® 3570C Positioner


Key	Description	Part Number	Key	Description	Part Number
9	Bias Spring, extension type Color Code: Black Pink Dark green		23	Name plate, aluminum	
10	Retaining ring, pl steel (2 req'd)		24*	Instrument gauge, plastic case/brass wetted parts For all types except 3570C 0-30 psi/0-.2 MPa/0-2 bar 0-60 psi/0-.4 MPa/0-4 bar	21B4037X012 21B4037X022
11	Beam, aluminum		25*	Cylinder bottom gauge, plastic case/brass wetted parts For 3570, 3571, 3573, 3577 0-160 psi/0-1.1 MPa/0-11 bar	21B4037X032
12	Flapper, SST (2 req'd)		26	Valve Assembly For 3570C only	
13	Flapper arm, aluminum		27	Hex nut, brass For 3570, 3571, 3573 (2 req'd) For 3572, 3576, 3577 (1 req'd) For 3570C (none req'd)	
14	Horizontal flexure strip (2 req'd)		28	Instrument tubing assembly, copper For all types except 3570C	
15	Vertical flexure strip		29	Relay assembly	See Repair Kits
16	Machine screw, pl steel (2 req'd)		30	Relay gasket, (2 req'd) Chloroprene (std. const.) Fluorocarbon (hi-temp. const.)	
17	Machine screw, pl steel For 3570, 3570C, 3571 (12 req'd) For 3572, 3573, 3576, 3577 (11 req'd)		31	Machine screw, pl steel For 3570, 3570C, 3571 (6 req'd) For 3572, 3573, 3576, 3577 (3 req'd)	
18	Range Spring, pl steel	See table 5			
19	Spring retainer, SST	See table 7			
20	Spring lock, SST				
21*	Bellows assembly, brass To 3.4 bar (50 psig) High pressure bellows, brass, over 3.4 bar (50 psig)	1H8610000A2 1H9010000A2			
22	Bellows post, brass (2 req'd)				

Key	Description	Part Number
32	Cap screw, pl steel (2 req'd)	
33*	O-ring Nitrile (std. const.) Fluorocarbon (hi-temp. const.)	1C853806992 1C8538X0052
34	Spring anchor, SST	
35	Machine screw, pl steel (2 req'd)	
36	Pipe plug, pl steel	
37*	Cover gasket, Cork (std. const.) Silicone (hi-temp. const.)	1H853804042 1H853804142
38	Cover screw, pl steel (4 req'd)	
39	Cover, aluminum	
40	Washer, brass plated (2 req'd)	
41	Relay blank, aluminum (see figure 14) For 3572, 3573, 3576, 3577	
42	Screw, SST (see figure 14) For 3572, 3573, 3576, 3577 (3 req'd)	
43	Label, paper For direct-acting units For reverse-acting units	
45	Cylinder tubing assembly, copper For 3570, 3571, 3573, 3577	
46	Bolt, brass w/o restrictor assembly (2 req'd) w/restrictor assembly (1 req'd)	
47	Restrictor assembly, SST	
48	Bias spring, compression type, pl steel Color Code: Silver Light blue Red Light green Brown	
49	Service tee, iron For 3570C only	
50	Pipe nipple, pl steel For 3570C only	
51	Pipe tee, iron For 3570C only	
52	Compression plug, brass For 3570C only (2 req'd)	
53	Adaptor, brass For 3570C only (2 req'd)	
54*	Cylinder top gauge, plastic case/brass wetted parts, For 3570, 3571, 3572, 3576 triple scale, 0-160 psi/0-1.1 MPa/0-11 bar dual scale, 0-160 psi/0-11 kg/cm ²	11B4040X032 11B4040X062

Note

Refer to figure 13 for keys 55 through 26E.

55	Mounting bracket, aluminum For 3571, 3576, 3577
56A	Spring retainer, pl steel For 3571, 3576, 3577
56B	Set screw, pl steel For 3571, 3576, 3577 (2 req'd)



NOTE:

1 RELAY BLANK AND SCREWS (KEY 42 AND 42) ARE INSTALLED WHERE SHOWN FOR 3573 AND 3577 POSITIONERS. FOR 3572 AND 3576 POSITIONERS, THESE PARTS ARE INSTALLED ON THE OPPOSITE SIDE OF THE POSITIONER

40A9335-C
A32301L

Figure 13. Feedback Wire Assembly (Typical with Fisher® 3571, 3576, and 3577 Positioners)


Key	Description	Part Number
56C	Boot, chloroprene For 3571, 3576, 3577	
56D	Spring wire, pl steel For 3571 For 3576, 3577	
56E	End bearing For 3571, 3576, 3577	
75	Tubing, copper (specify length)	
77	Elbow, 3/8-inch, brass (specify quantity)	
78	Connector, 3/8-inch brass (specify quantity)	
84	Spring retainer spacer, SST	See table 8
88	Torsion spring, steel	
89	Extension cover, aluminum	

Note

Refer to figure 14 for keys 86 through 104.

86	Spring cap assembly, aluminum and SST
87	Machine screw, pl steel (2 req'd)
90	Machine screw, pl steel (6 req'd)
91	Positioner cable
92	Actuator cable
93	Cable strap, brass
94	Cap screw, pl steel (3 req'd)
95	Hex nut, pl steel
96	Cable spool, acetal plastic

3570 Positioners



41A7131-A
B1839/IL

Key	Description	Part Number
97	Spring guide, aluminum	
98	Warning plate	
99	Self-tapping screw, pl steel	
100	Cap screw, pl steel (2 req'd)	
101	Positioner extension assembly, aluminum	
102	Washer, SST	
	For 3572, 3576 (1 req'd)	
	For 3570, 3571, 3573, 3577 (2 req'd)	
235	Spring retainer spacer, SST	
	104.8 mm (4-1/8 inches) maximum actuator travel, 54.0 mm (2-1/8 inches) or less valve travel	
	206.4 mm (8-1/8 inches) maximum actuator travel, between 54.0 mm (2-1/8 inches) and 104.8 mm (4-1/8 inches) valve travel (2 different spacers req'd)	
	206.4 mm (8-1/8 inches) maximum actuator travel, less than 54.0 mm (2-1/8 inches) valve travel (2 req'd)	

Figure 14. Fisher® 3570P and 3570PC Positioner

3570 Positioners

Fisher and FlowScanner are marks owned by one of the companies in the Emerson Process Management business division of Emerson Electric Co. Emerson Process Management, Emerson, and the Emerson logo are trademarks and service marks of Emerson Electric Co. All other marks are the property of their respective owners.

The contents of this publication are presented for informational purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available upon request. We reserve the right to modify or improve the designs or specifications of such products at any time without notice. Neither Emerson, Emerson Process Management, nor any of their affiliated entities assumes responsibility for the selection, use or maintenance of any product. Responsibility for proper selection, use, and maintenance of any product remains solely with the purchaser and end-user.

Emerson Process Management

Marshalltown, Iowa 50158 USA

Sorocaba, 18087 Brazil

Chatham, Kent ME4 4QZ UK

Dubai, United Arab Emirates

Singapore 128461 Singapore

www.Fisher.com